

Sorter Garbo



Toebehoren



01
Emmer 8 l
150 x 225 x 340 mm
700026
FUN 133.0251.264
€ 24,80 (excl. BTW)
€ 30,01 (incl. BTW)



02
Emmer 12 l
150 x 300 x 340 mm
700030
FUN 133.0251.265
€ 32,20 (excl. BTW)
€ 38,96 (incl. BTW)



03
Emmer 12 l
225 x 225 x 340 mm
700029
FUN 133.0251.269
€ 49,30 (excl. BTW)
€ 59,65 (incl. BTW)



04
Emmer 18 l
225 x 300 x 340 mm
700033
FUN 133.0251.270
€ 51,70 (excl. BTW)
€ 62,56 (incl. BTW)



05
Schaal
125 x 165 x 75 mm
700036
FUN 133.0251.271
€ 20,70 (excl. BTW)
€ 25,05 (incl. BTW)



06
Deksel
voor emmer 18 l
700034
FUN 133.0284.696
€ 10,50 (excl. BTW)
€ 12,71 (incl. BTW)



07
Deksel
voor emmer 18 l met
actieve koolstoffilter
700035
FUN 133.0284.697
€ 23,90 (excl. BTW)
€ 28,92 (incl. BTW)



08
Deksel
voor emmer 12 l
(Enkel passend op
rechthoekige 12 l
emmer)
700031
FUN 133.0200.695
€ 9,90 (excl. BTW)
€ 11,98 (incl. BTW)



09
Deksel
voor emmer 12 l met
actieve koolstoffilter
(Enkel passend op
rechthoekige 12 l
emmer)
700032
FUN 133.0200.699
€ 20,30 (excl. BTW)
€ 24,56 (incl. BTW)



10
Deksel
voor emmer 8 l
700027
FUN 133.0200.694
€ 9,40 (excl. BTW)
€ 11,37 (incl. BTW)



11
Deksel
voor emmer 8 l
met actieve kool-
stoffilter
700028
FUN 133.0200.698
€ 19,10 (excl. BTW)
€ 23,11 (incl. BTW)